

Control and Automation IC2122 Robotics Lab with VREP

Instructor: Louis Wong

Industrial Centre

The Hong Kong Polytechnic University

V-REP Tools

Object Position:

1. Select the object



3. Position: X, Y, Z





1. Select the object

2. Click



3. Orientation: Alpha (α), Beta (β), Gamma(γ)








INDUSTRIAL CENTRE 工業中心




Task 2: Inverse Kinematics





Start-up — V-REP


Start the V-REP (Task2_vrep.bat)





Start-up – Anaconda Navigator


Start the Anaconda Navigator on Taskbar or search Windows






Start-up – Spyder

Launch Spyder




Start-up – Spyder




Start-up – Spyder


Open Python file at editor



• Run the program at Spyder




D:\01-Home\IoT\IC2122-Robotics\Task2



Start-up — Control panel window


- Control panel window will be appeared after running the program
- After switching to the V-REP, the control panel window will be hidden
- Click the Control panel window icon to open it.





Start-up

V-REP interface:



INDUSTRIAL CENTRE 工業中心

V-REP Joint Angle - Control Panel

- Target Configuration
 - Set Target (T)
 (Input your value at Console)
 - Set target Position (X, Y, Z)
 - Set target Orientation (Alpha, Beta, Gamma)
 - 2. Set Position (P)(Input your value at Console)
 - Set target Position (X, Y, Z)
 - 3. Set Orientation (O)(Input your value at Console)
 - Set target Orientation (Alpha, Beta, Gamma)

```
Input Position X: 0.4

Input Position Y: 0

Input Position Z: 0.435

Input Orientation Alpha (in degree): 0

Input Orientation Beta (in degree): 90

Input Orientation Gamma (in degree): 180
```

Input Position X: 0.4

Input Position Z: 0.435

Input Orientation Alpha (in degree): 0

Input Orientation Beta (in degree): 90

Input Orientation Gamma (in degree): 180

Input Position Y: 0

Joint Angle configuration disabled

Tolle Position (L)

орен ког (т)

Close Roz (I)

--- End-Effector (Tip) Position and Orientation---

X: -0.0048 m

Y: 0.3887 m

Z: 1.1039 m

50.8909

Alpha: 135.4654

4 B

Beta: -87.2704

Gamma:

Set Target (I)

Set Position

Set Orientation (0)



V-REP Joint Angle — How to use "Set Target" button?

- How to use the "Set Target" button?
 - Click "Set Target" button





- 2. Switch to the Spyder IPython Console
- 3. Input Position or Orientation value
- 4. Press "Enter" to confirm the inputted value
- Repeat above two steps(X, Y, Z, Alpha, Beta, Gamma)
- 6. The UR3 will be moved based on the setting







IC2122 – Task 2a


• Task 2a: Move the end-effector to the RED block using Inverse Kinematics and write down the procedure.



(Remark: Adjust the end-effector vertically to the ground)

Red Block	Position X	Position Y	Position Z
Position:	0.125 m	-0.35 m	0.435 m

	Joint Angle	
Base (Joint1)	<< (W) < > (Q) >>	+37.65 deg
Shoulder (Joint2)	<< (S) < > (A) >>	-70.57 deg
Elbow (Joint3)	<< (X) < > (Z) >>	-0.33 deg
Wrist 1 (Joint4)	<< (R) < > (E) >>	+162.7 deg
Wrist 2 (Joint5)	<< (F) < > (D) >>	-89.42 deg
Wrist 3 (Joint6)	<< (V) < > (C) >>	-142.32 deg



Final Goal



IC2122 – Task 2b

• Task 2b: Pick the BLUE block and place it on the table using Inverse Kinematics




(Remark: Make the end-effector vertically to the ground for picking

and horizontally to the table for placing)

BLUE Block original	Position X	Position Y	Position Z
Position:	0.35 m	0.0225 m	0.435 m

BLUE Block final	Position X	Position Y	Position Z
Position:	≈ -0.667 m	≈ 0 m	0.846 m





and write down the procedure.

IC2122 – Task 2c

Stop the program by holding "Ctrl" and clicking "C" (IPython console)



Open a new console by holding "Ctrl" and clicking "D" (IPython console)

_ | 🗸 🔲 - |


- Close the previous V-REP
- Start a new V-REP (Task2c vrep.bat)

Switch to Spyder and open Tack2c.py

(D:\01-Home\IoT\IC2122-Robotics\Task2)

Run the program (Spyder)






IC2122-Robotics

Application Tools

IC2122 – Task 2c

Task 2c interface



Task 2c: Moving the end-effector to the BLUE block using

Inverse Kinematics often provides different solutions or approaches.

a) Observe and discuss the below 3 solutions.

--- Multiple Inverse Kinematics Solution for arriving blue block---

Solution 1

Solution 2


Solution 3

b) Suggest the method to create the unique solution (e.g. guide)




Task2 – Troubleshoot

• Step 1: Switch to the Spyder IPython Console



- Step 2: Stop the program by holding "Ctrl" and clicking "C"
- Step 3: Open a new console by holding "Ctrl" and clicking "D"
- Step 4: Stop the V-REP simulation





Step 5: Run the program at Spyder

